

Handheld calibration tool / Handheld cleaning tool Tragbares Kalibrierwerkzeug / Tragbares Reinigungswerkzeug Outil d'étalonnage portatif / Outil de nettoyage portatif

Operating Instructions

Bedienungsanleitung Manuel d'utilisation

We reserve the right to make technical changes without notice. Technische Änderungen vorbehalten. Sous réserve de modifications techniques.

© Bürkert SAS, 2017

Operating Instructions 1704/00_EU-ML_00569085 / Original DE

Table of contents



1	OPE 1.1 1.2	RATING INSTRUCTIONS Definition of terms Symbols used	4
2	INTE	NDED USE	5
3	BASI	C SAFETY INFORMATION	5
4	GEN 4.1 4.2 4.3	ERAL INFORMATION Contact address Warranty Information on the Internet	6 6
5	PRO	DUCT DESIGN	7
6	TECH 6.1 6.2 6.3 6.4 6.5 6.6	HNICAL DATA Conformity Standards Conditions of use Mechanical data Electrical data Rating plate	
7	CALI	BRATION TOOL ELECTRICAL CONNECTION	9
8	COM 8.1 8.2	IMISSIONING Safety instructions Inserting batteries	9

9	OPERATION AND FUNCTION		10
	9.1	Safety instructions	10
	9.2	Calibrating the sensor cube	10
	9.3	Cleaning the sensor cube	11
10	MAIN	ITENANCE AND TROUBLESHOOTING	13
	10.1	Changing the batteries	13
	10.2	Troubleshooting	13
11	SPAF	RE PARTS	13
12	TRAN	ISPORT, STORAGE, DISPOSAL	14



1 OPERATING INSTRUCTIONS

The Operating Instructions describe the entire life cycle of the product. These instructions should be kept within easy access at the place of use.

Important safety information!

- Read these Operating Instructions carefully.
- Pay particular attention to the safety information, intended use and operating conditions.
- Persons working with the product must read and understand these Operating Instructions.

1.1 Definition of terms

In these Operating Instructions, the term "product" refers to the following versions of tool type MZ15:

- Portable calibration tool for sensor cubes of the type 8905
 on-line analysis system
- Portable cleaning tool for sensor cubes of the type 8905
 on-line analysis system

In these Operating Instructions, the term "system" refers to the type 8905 on-line analysis system

1.2 Symbols used

Warns against an imminent danger.

► If ignored, death or serious injury will result.

Warns against a potentially dangerous situation.

If ignored, serious injury or death may result.

Warns of possible danger.

▶ If ignored, substantial or minor injuries may result.

NOTICE

Warns against material damage.



Important advice and recommendations.



Refers to information in the Operating Instructions or in other documents.



 \rightarrow

 \checkmark

- Indicates a procedure that must be carried out.
- Indicates a result.

Menu Representation for software interface texts.

Intended use



2 INTENDED USE

Use of this product that does not comply with the instructions could present risks to people and the environment.

The product in the calibration tool version is designed for the calibration of individual sensor cubes MS01, MS03 and MS04.

The product in the cleaning tool version is designed for cleaning the fluidic circuit of individual sensor cubes MS01, MS03, MS04 and MS05.

The product must be used in compliance with the characteristics, operating conditions and conditions of use. This information can be found in the contract documents, the operating instructions and on the rating plate.

The product:

- do not use in an outdoor area.
- use only with calibration or cleaning solutions approved and specified by Bürkert.
- use only in conjunction with external devices or components recommended by Bürkert.
- use in a frost-protected location.
- protect from electromagnetic interference.
- operate only in perfect working order and ensure appropriate storage, transport, installation and control.
- use only for its intended purpose.

3 BASIC SAFETY INFORMATION

These safety instructions do not take account of any hazards and events arising during installation, operation and maintenance. The operator is responsible for ensuring that local safety regulations in relation to staff are respected.

 $\underline{\wedge}$

Danger due to the nature of the operating agents.

- Observe the rules in force concerning accident prevention and safety and which relate to the use of hazardous liquids.
- Observe the information on the safety data sheet for the cleaning solution. The relevant data sheet can be found at the address given on the bottom of the bottle.
- Wear personal protective equipment when working with cleaning solutions.
- Dispose of any waste in compliance with the information provided in the safety data sheet. Local regulations regarding disposal shall be observed.

Various dangerous situations.

To avoid personal injury take care:

- to use the product only if in perfect working order and in compliance with the instructions provided in these Operating Instructions.
- not to use this product in potentially explosive areas.



- not to make any modifications to the product and not to subject it to mechanical loads.
- to ensure that only trained personnel perform installation and maintenance work.
- ▶ to observe best industry practice.

NOTICE

Only operate the product with 4 LR6 AA batteries.

NOTICE

Elements and components sensitive to electrostatic discharges.

This product contains electronic components sensitive to electrostatic discharges They may be damaged if they are touched by an electrostatically charged person or object. In the worst case, these components will become defective immediately or will fail when energized.

- Comply with the requirements according to EN 61340-5-1 in order to eliminate or minimize the possibility of damage through sudden electrostatic discharge.
- · Do not touch any of the live electrical components.

4 GENERAL INFORMATION

4.1 Contact address

To contact the manufacturer of the product, use the following address:

Bürkert SAS

Rue du Giessen

BP 21

F-67220 TRIEMBACH-AU-VAL

The addresses of our international branches can be found on the Internet at:

www.burkert.com

4.2 Warranty

The warranty is conditional on compliant use of the product in observance of the operating conditions specified in this manual.

4.3 Information on the Internet

You can find the Operating Instructions and technical data sheets for Bürkert products at: <u>www.burkert.com</u>

Product design



5 PRODUCT DESIGN



Fig. 1: Calibration tool description



Fig. 2: Cleaning tool description

6 TECHNICAL DATA

The following values are specified on the rating plate:

- Operating voltage/current consumption
- IP rating according to EN 60529/IEC 60529
- Fluid temperature range
- Pressure range

6.1 Conformity

The product complies with EU directives according to the EU declaration of conformity (if applicable).

6.2 Standards

The standards used to demonstrate conformity with the Directives can be consulted in the EU type examination certificate and/or the EU declaration of conformity (if applicable).

6.3 Conditions of use

Risk of injury from malfunction due to outdoor use.

Do not use the product in outdoor areas and avoid heat sources that could result in the permissible temperature range being exceeded.



Ambient temperature	+3+40°C
Air humidity	< 80%, without condensation
IP rating according to EN 60529	IP20

6.4 Mechanical data

Dimensions and weight: refer to the relevant data sheet at www.burkert.com

Part	Material	
Housing	ABS	
Screws	Stainless steel, passivated steel	
Rating plate	metallized polyester	
M12 plug	Zn, CuZn, Au, PA	
Parts in contact with fluid		
• Seal	EPDM, not replaceable	
Further materials	PA, POM, PPS, Silicone	

Fig. 3: Product materials

6.5 Electrical data

Power supply

4 AA LR6 batteries, 6 V total

6.6 Rating plate



Fig. 4: Rating plate description



7 CALIBRATION TOOL ELECTRICAL CONNECTION



Tab. 1: Pin assignment M12 device plug

→ Connect M12 plug of the calibration tool, with a büS cable available as an accessory, to the last M12 socket of the system.

8 COMMISSIONING

8.1 Safety instructions

Danger of injury from improper operation.

- Prior to commissioning, it must be ensured that operating personnel have read and fully understand the contents of the Operating Instructions.
- Pay particular attention to the safety recommendations and intended use.
- The product or system may only be commissioned by trained staff.

8.2 Inserting batteries

Before commissioning, insert 4 AA LR6 batteries in the battery compartment of the product, as shown in Fig. 5.





2. Pull out the battery compartment.
3. Open the battery compartment.
4. Insert batteries. Ensure correct positioning.
5. Push the closed battery compartment into the housing (see figure).
6. Replace housing cover.

9 **OPERATION AND FUNCTION**

Safety instructions 9.1



WARNING

Danger due to improper operation.

- Operating personnel must have read and understand the content of the Operating Instructions.
- Pay particular attention to the safety recommendations and intended use.
- The product or system must only be operated by adequately trained staff.

Calibrating the sensor cube 9.2

- The appropriate Operating Instructions are required for calibrating a sensor cube.
 - \rightarrow The sensor cube Operating Instructions can be downloaded from www.burkert.com.
- 1. Prepare one or two calibration solutions according to the sensor cube to be calibrated. See chap. 11 Spare parts.
- 2. Prepare an empty waste bottle. See chap. <u>11 Spare parts</u>.
- 3. Screw the empty waste bottle in the correct position of the bottle holder.
- 4. Screw the bottle with the first calibration solution in the correct position of the bottle holder.

Inserting batteries in the product Fig. 5:

Operation and function



The calibration of the sensor cube is controlled via the system display or using Bürkert Communicator Software.

- → Connect the calibration tool to the system or the Bürkert Communicator Software using büS. See chap. <u>7 Calibration tool electrical connection</u>.
- Select the sensor cube to be calibrated on the system display or in the Bürkert Communicator: the LED of the sensor cube flashes.
- 6. Remove the sensor cube from the backplane of the system and fit and lock it on the backplane of the product.



 \rightarrow Keep the product upright during calibration:

- so that the fluid flows correctly through the sensor cube;
- and so that the check valves function correctly.
- Reselect the sensor cube in the system display or in Bürkert Communicator: the LED of the sensor cube flashes.
- 8. Call up the calibration wizard in the maintenance view of the sensor.
- 9. Refer to the subsequent steps in the sensor cube Operating Instructions.
- 10. After calibrating, remove the sensor cube from the backplane of the product and insert and lock it on the backplane of the system.

9.3 Cleaning the sensor cube

Danger due to the nature of the operating agents.

- Observe the rules in force concerning accident prevention and safety and which relate to the use of hazardous liquids.
- Observe the information on the safety data sheet for the cleaning solution. The relevant data sheet can be found at the address given on the bottom of the bottle.
- Wear personal protective equipment when working with cleaning solutions.
- Dispose of any waste in compliance with the information provided in the safety data sheet. Local regulations regarding disposal shall be observed.

Sensor fluid system cleaning takes place in two steps:

- 1. Dissolve the contaminants with a cleaning solution.
- 2. Flush the cleaning solution with a flushing solution.

9.3.1 Dissolving contaminants

1. Prepare a cleaning solution according to the type of contaminant. See chap. <u>11 Spare parts</u>.



The cleaning solution is pumped in the circuit and thinned by impurities.

- $\rightarrow\,$ Use a new cleaning solution every five cleanings.
- 2. Screw the bottle with the cleaning solution onto the product's bottle holder.
- 3. Remove the sensor cube from the backplane of the system and fit and lock it on the backplane of the product.



- $\mathbf{p} \rightarrow \mathbf{Due}$ to the mounting position of the sensor cube, always keep the product upright during cleaning.
- 4. Press the actuator button in order to allow the cleaning solution to flow through the fluid system of the sensor cube. The pump will operate so long as the button is pressed. Adjust the pumping duration according to the degree of contamination of the sensor cube fluid system: see <u>Tab. 2</u>.

Degree of contamination	Pumping duration (s)
Light contamination	10
Average contamination	20
Heavy contamination	60

- Tab. 2: Recommended pumping durations according to degree of contamination
- 5. Remove the sensor cube from the backplane of the product and lay flat.
- 6. Allow the cleaning solution to soak in for a time dependent on the degree of contamination. See <u>Tab. 3</u>.

Degree of contamination	Soaking time (min)
Light contamination	5
Average contamination	10
Heavy contamination	15

- Tab. 3: Recommended soaking time depending on degree of contamination
- 7. After the soaking time, ensure that no cleaning solution remains in the sensor cube. See chap. <u>9.3.2</u>.

9.3.2 Flush the cleaning solution

- 1. Prepare a flushing solution. See chap. <u>11 Spare parts</u>.
 - The flushing solution is pumped in the circuit.
 - \checkmark \rightarrow Use a new flushing solution every five flushings.
- 2. Screw the bottle with the flushing solution in place of the cleaning solution on the product's bottle holder.
- 3. Fit and lock the sensor cube on the backplane of the product.
- 4. Always keep the product upright during flushing.
- 5. Operate the pump for at least 10 s; press the actuator button for 10, 20 or 30 s according to the degree of contamination.

Maintenance and troubleshooting



10 MAINTENANCE AND TROUBLESHOOTING

10.1 Changing the batteries

NOTICE

Environmental damage caused by incorrect disposal of batteries.

Observe local regulations when disposing of batteries.

 \rightarrow To change the batteries, follow the procedure in chapter <u>8.2</u>.

10.2 Troubleshooting

A warning or error may be generated during calibration.

→ To resolve this, refer to the Operating Instructions for the calibrated sensor cube, at <u>www.burkert.com</u>.

11 SPARE PARTS



CAUTION

Risk of injury and/or damage caused by the use of nonoriginal parts.

Non-original accessories and unsuitable replacement parts can cause injuries and damage the product and the surrounding area.

► Use only original accessories and spare parts from Bürkert.

Accessories	Order code	
Cleaning solution		
Cleaning solution, acid, 250 ml	807478	
Cleaning solution, alkaline, 250 ml	807486	
Calibration solution		
Buffer solution pH 5.00 (20 °C), 50 ml	806698	
Buffer solution pH 7.00 (20 °C), 50 ml	806699	
Buffer solution pH 9.00 (20 °C), 50 ml	806700	
Redoxpotential 475 mV, 50 ml	807045	
Conductivity 5 mS/cm, 50 ml	807199	
Flushing solution		
Flushing solution, 50 ml	806709	
Flushing solution, 250 ml	806710	



Accessories	Order code
Electrical accessories	
büS cable, plug/socket, straight, 1 m	772404
büS cable, plug/socket, straight, 3 m	772405
büS cable, plug/socket, straight, 5 m	772406
büS Y-distributor	772420

12 TRANSPORT, STORAGE, DISPOSAL

NOTICE

Inadequately protected products may be damaged during transport.

- Transport the product in shock-resistant packaging and away from humidity and dirt.
- Comply with the permissible storage temperature.

Poor storage can damage the product.

- Store the product in a dry place away from dust.
- Before storage, pump any cleaning solution out of hoses.
- Storage temperature -40...+55 °C.

Environmental damage due to product parts contaminated by fluids.

- When disposing of cleaning solutions, follow the instructions on the safety data sheet. The safety data sheet can be found at http://sds-id.com/200124-7
- Dispose of the product and its packaging in an environmentally friendly manner.
- Comply with applicable environmental and disposal regulations. Environmental damage caused by incorrect disposal of batteries.
- Observe local regulations when disposing of batteries.



www.burkert.com